
USPS FIRST-CLASS PKG

Logistics Label Printer

User Guide

CONTENT

A Overview

1. Quick Start Video
2. Product Overview
3. Printer Started
4. Label Loading
5. Feed Button
6. LED Status Light
7. Maintenance
8. Tips for Preparation
9. Safety Notices
10. Download the Driver
11. Download the APP
12. Windows PC Bluetooth connection

B macOS

Step 1: Security & Privacy Setting
Step 2: Driver Installation
Step 3: Printer Setup

C Windows

Step 1: Driver Installation
Step 2: Printer Setup

D Support

1. Adobe Use Tips
2. Labelife Use Tips
3. Solution for Not Finding the Printer

Live Technical Support via Email , Phone and Remote-Desktop

Tel: +1 833 940 3818 (US and CA only)
Service time: Mon-Fri 9AM-5PM (EST)
Email: after-service@omezizy.com
Whatsapp: +86 1 316 066 9859

YouTube Search for "omezizy" , You will find the tutorial videos.

www.omezizy.com

1. Quick Start Video

A

The printer is a very capable printer. You can print barcodes, shipping labels, name badges, warehouse labels, food nutrition labels, amazon FBA labels and labels of all sizes with it. It' s the perfect partner for your business with its economical, reliable and high-efficient features.

You can get a more comprehensive and detailed video tutorial in the following ways:
Method 1: Download the latest driver from official website
Method 2: Complimentary USB driver

Please kindly take a short time to watch the setup video. It will guide you through the setup process step by step.

2. Product Overview

A

Package contents

Printer*1, Power Cord*1, Power Adapter*1, USB Cable*1, USB Driver*1, Quick Start Guide*1, Start Label*1, TC Adapter*1

Printer components


Status Light
Feed Button
Cover
Tear Bar


Cover Release Button
DC adapter connector
Paper Guide
USB port
Power Switch


Thermal Printer head
Platen Roller

> **Please take a moment to thoroughly read this user guide.** Incorrect operation may result in damage to the printer or your physical injury.

3. Pinter Started

1. Ensure that the printer is OFF. The power switch is switched to O. (I:On; O:Off)



2. Attach the power cord to the adapter.



3. Plug the adapter cable into Circular DC adapter connector of the printer.



4. Plug the power cord into socket.



5. Connect the USB cable to the printer.



6. Connect the other end of the USB cable to the computer.

7. Turn the printer ON with the power switch. (I:On; O:Off)



4. Label Loading

The printer is capable of working with label width range from 1" to 4.6" (25.4 to 117 mm). To print on different labels correctly, the printer needs to identify your label size before it starts printing.

> To run the automatic label identification, please follow these steps:

1. Turn on the printer. (I:On; O:Off)



2. Adjust the paper guide to match the label size.



3. Insert label and ensure it is straight and smooth as shown.
Note: The print side should face up.



4. Make sure the label is automatically caught by the printer.



5. Press and hold Feed Button. After the blue light flashes 2 times, release the Feed Button.



6. The printer will move the label back and forth to learn the gap size and other properties of your label.



NOTE: Please run the label size identification every time you change your label. (See picture 5 & 6)

If the learning fails and the indicator blinks blue, please calibrate the sensor. See 5.Feed Button for details.

> **Continue to Driver Installation**

5. Feed Button

Desired Action	Execution
Skip a label	When the printer is standby and ready (not in the middle of printing), press the Feed Button once.
Print test page	Insert the label, ensure it is straight and smooth. When the printer is standby, **press** and **hold the Feed Button for about 4 seconds. After** the **blue light flashes 1 times,** then release the Feed Button.
Run the automatic label identification (for labels with gaps)	Insert the label, ensure it is straight and smooth. When the printer is standby, **press** and **hold the Feed Button for about 6 seconds. After** the **blue light flashes 2 times,** then release the Feed Button.
Run the automatic label identification (for labels with black marks)	Insert the label, ensure it is straight and smooth. When the printer is standby, **press** and **hold the Feed Button for about 8 seconds. After** the **blue light flashes 3 times,** then release the Feed Button.
Restore factory setting	Insert the label, ensure it is straight and smooth. When the printer is standby, **press** and **hold the Feed Button for about 10 seconds. After** the **blue light flashes 4 times,** then release the Feed Button.
Sensor calibration	Unload the label. When the printer is standby, **press** and **hold the Feed Button for about 12 seconds. After** the **blue light flashes 5 times,** then release the Feed Button. **Run the automatic label identification again after sensor calibration.**
Pause printing	When the printer is printing, press the Feed Button once.
Resume printing	When the printer pauses printing, press the Feed Button once to resume printing.
Clear printing data	When the printer pauses printing, press the Feed Button twice to clear the printing data.

6. Led Status Light



Light	Printer status
Solid blue	Standby and Ready
Blue flashing slowly	Label jams or label detection error
Blue flashing quickly	Wrong media tracking
Solid red	Printer head is over-heated
Red flashing slowly	Paper shortage
Red flashing quickly	Cover is not closed
Solid purple	Printing
Purple flashing quickly	Pause printing

7. Maintenance

▶ Printer head cleaning steps

1. **Turn the printer off** , remove the power cord and open the cover. (See picture 1)
2. **Wait until the printer head cools down** . (The printer head may be very hot after printing)
3. Completely **clean the printer head using an alcohol swap (Not with water).** (See picture 2)
4. Wait **until the alcohol has completely vaporized**, then close the cover.
5. Connect the power cord and **print a test page** to check if it is clean.



Picture 1



Picture 2

NOTICE

Ensure power is off when performing maintenance.
Do not touch or scratch the printer head, the roller or the sensors.

8. Tips for Preparation A

1. **Avoid using poor quality labels** as they may damage the printer.

2. **Clean the printer head** regularly.

3. Connect the printer to the **same USB port on your computer every time.** This can avoid creating duplicate copies on the printer.

4. **If paper is jammed**, please refer to "Printer head Cleaning Steps" in "7. Maintenance".

9. Safety Notices A

1.Do not bend the power cord excessively or place objects on the cord.

2. Keep the printer **out of reach of children**.

3. Use only approved accessories and **do not try to disassemble or repair the unit by yourself.**

4. **Keep the printer away from water** and other objects that could penetrate the components.

5. **Unplug the printer when it is not in use for long periods.**

6. **Do not use the printer if you find any irregularities** as these could result in fire or electrocution.

7. **Do not touch the printer head.** The printer head can be over-heated after printing.

10. Download the Driver

Method 1:
Install the latest printer driver from the USB driver attached.



1.PM-241-BT-Getting Started Video
2.PM-241-BT-Driver
3.PM-241-BT-Support & How-Tos
4.Setting tool
Labels-Sample.pdf
PM-241-BT-Quick Start Guide.pdf

Method 2:
Download the latest driver from official website

> Please run the downloaded software and follow the hints to complete the installation.



Printer-1.3.1.pkg
(Mac Driver Installer)



Label Printer Driver
Setup_Release_v1.2.7.exe

Note: Before the installation, please ensure the printer is connected and turned on!

① Mac OS: For more details, see section B

② Windows: For more details, see sectionC

11. Download the App

1. Search "Labelife" on App Store or

2. Or please scan the QR Code to

1. Search "Labelife" on App Store or Google Play to get the app.

2. Or please scan the QR Code to download the App.

Google Play

App Store

Labelife

3.Turn on Bluetooth, connect the printer in two steps


①
Open APP


②
Click the " 🖨 " button to connect to Bluetooth.

Note:

4. Due to the mobile phone system requirements (Android only), App needs access to location, you need to enable GPS and confirm authorization.
5. Make sure to select 4"×6" file to print.
6. iOS cannot import PDFs directly. Open the files and share it to labelife app.

12. Windows Bluetooth connection

1. Connect USB cable
2. Feed paper
3. Calibrate printer
4. Install driver via USB firstly (not bluetooth)
(Please refer to "Step 4-1: Driver Installation" in "For windows")
5. Keep USB cable connected still
6. Set up Bluetooth:
① Add bluetooth (Not necessary step)
② Match COM port (Not necessary step)
The video tutorial is on the complimentary USB drive.

macOS STEP 1.
Security & Privacy Setting

B

(1) Click on the "pkg" installer to begin.

(2) If the driver can not be opened, please give permission to it first. Click "OK" and follow the steps below to allow the macOS system to process the installation.



"Printer-1.3.1.pkg" cannot be opened because it is from an unidentified developer.

macOS cannot verify that this app is free from malware.

Safari downloaded this file today at 4:28 PM from **shopify-delivery-app-storage.s3.amazonaws.com**

(3) Click "" and go to "System Preferences".



Finder
File
Edit
Viev
About This Mac
System Preferences...
Location
App Store...

(4) Select "Security&Privacy".


Security & Privacy

(5) Under "General", click "Open Anyway" to set up.


Security & Privacy
Search
General
FileVault
Firewall
Privacy
Change Password...
Set Lock Message...

A login password has been set for this user

☑ Require password 5 minutes after sleep or screen saver begins

Show a message when the screen is locked

✓ Disable automatic login



Allow apps downloaded from:

○ App Store

● App Store and identified developers

"LabelPrinter-1.3.1.pkg" was blocked from use because it is not from an identified developer.

Click the lock to make changes.

(6) Input the password of your Mac. Then click "Modify Settings".
Note: If you didn’ t set a password, please skip this step.



System Preferences is trying to modify your system settings.

Enter your password to allow this.

User Name: wly

Password:

(7) Click "Open" and continue to install the driver.



macOS cannot verify the developer of “Printer-1.3.1.pkg” Are you sure you want to open it?

By opening this app, you will be overriding system security which can expose your computer and personal information to malware that may harm your Mac or compromise your privacy.

Safari downloaded this file today at 4:28 PM from **shopify-delivery-app-storage.s3.amazonaws.com**



Welcome to the Label Printer Installer

You will be guided through the steps necessary to install this software.

Install Label Printer
Introduction
Destination Select
Installation Type
Installation
Summary
Go Back
Continue

macOS
STEP 2. Driver Installation

B

(1) Follow the installation steps until you receive the"Installation was successful" message.



The installation was completed successfully.

The installation was successful.

The software was installed.

Install Label Printer
Introduction
Destination Select
Installation Type
Installation
Summary


Go Back
Close

(2) Click " " and go to "System Preferences".


Finder
File
Edit
Vie
About This Mac
System Preferences...
Location
App Store...

(3) Select "Printer & Scanners".


Printers &
Scanners

(4) Click "+" to add a printer .


Printers & Scanners
Search
+
?

No printers are available.
Click Add (+) to set up a printer.

Default printer: Last Printer Used

Default paper size: 100*150mm

Click the lock to make changes.

(5) Select "PM-241-BT"-> Click "Select Software" under "Use" .


Add Printer
Search
Name
Kind
PM-241-BT
USB
Use
✓
PM-241-BT
Auto Select
Select Software...
Other...

Name: PM-241-BT

Location: it's MacBook Air

(6) Select "PM-241-BT" and click "OK" .


Printer Software
PM-241-BT
Cancel
OK

241-

(7) Click "Add".


Add Printer



Name	Kind
PM-241-BT	USB

Name: PM-241-BT
Location: it's MacBook Air
Use: PM-241-BT

(8) Print test page

① Click "Open Print Queue…"



Printers & Scanners
Search
Printers
PM-241-BT
Idle, Last Used
PM-241-BT
Open Print Queue...
Options & Supplies...
Share this printer on the network
Sharing Preferences...
+
−
Click the lock to make changes.
?

Location: it's MacBook Air
Kind: PM-241-BT
Status: Idle

Default printer: Last Printer Used
Default paper size: 100*150

② Click "Printer" and "Print Test Page"



Pause
Make Default ⌘D
Settings ⌘S
Supply Levels...
Print Test Page
Error Log
Printers & Scanners Preferences... ⌘L

macOS
STEP 3. Printer Setup

(1) Print a sample label: Open a desired file (e.g. a PDF) through Preview .


Adobe Acrobat (default)
Books
ColorSync Utility
Droplet
Labelife
Preview
Safari
Open
Open With
Move to Trash
Get Info
Rename
Compress "Labels-Sample.pdf"
Duplicate
Make Alias

(2) Click "File" and choose "Print".


Pre
File
View
Go
Tools
Wind
New from Clipboard ⌘N
Open... ⌘O
Open Recent
Close Window ⌘W
Close Selected PDF Document ⇧⌘W
Save ⌘S
Duplicate ⇧⌘S
Rename...
Move To...
Revert To
Enter Password...
Import from iPhone or iPad
Import from Camera...
Import from Scanner...
Take Screenshot
Export...
Export as PDF...
Share
Print... ⌘P
PR
Joh
123
CAR
SHIP
TO:

(3) Select "Show Details".


1 of 1
P
PRIORITY MAIL 2-DAY™
John Smith
1234 BARNES RD
CARSON NV 30000
99
SHIP TO:
DO NOT SHIP
11 CAMPBELL AVE
CAMPBELL CA 95008
USPS TRACKING #
DO NOT SHIP
?
Show Details
PDF
Cancel
Print

Printer: PM-241-BT

Copies: 1

Pages: ● All
○ From: 1 to: 1

(4) Check your printer and choose a paper size from "Paper Size".


Printer
✓ PM-241-BT
Presets
Add Printer...
Copies
Printers & Scanners Preferences...


SAMPLE LABEL
6 LB PRIORITY MAIL
ZONE 4 NO SURCH
Printer
Presets
Copies
Pages
Paper Size
Orientation
4.00x4.00" 4.00 by 4.00 inches
4.00x5.00" 4.00 by 5.00 inches
4.00x6.00" 4.00 by 6.00 inches
4.00x6.50" 4.00 by 6.50 inches
4.00x13.00" 4.00 by 13.00 inches
100mmx100mm 3.93 by 3.93 inches
100mmx120mm 3.93 by 4.72 inches
100mmx150mm 3.93 by 5.90 inches
100mmx170mm 3.93 by 6.68 inches
100mmx180mm 3.93 by 7.08 inches
100mmx200mm 3.93 by 7.86 inches
100mmx250mm 3.93 by 9.83 inches
Manage Custom Sizes...

Paper Size: ✓ 100*150mm 3.94 by 5.91 inches

① If there is no suitable label size for you, please click "Manage Custom Sizes" to add the size.


Tools
Window
3.00x3.00" 3.00 by 3.00 inches
3.00x5.00" 3.00 by 5.00 inches
3.25x2.00" 3.25 by 2.00 inches
3.25x5.00" 3.25 by 5.00 inches
3.25x5.50" 3.25 by 5.50 inches
3.25x5.83" 3.25 by 5.82 inches
3.25x7.83" 3.25 by 7.82 inches
3.50x1.00" 3.50 by 1.00 inches
4.00x1.00" 4.00 by 1.00 inches
4.00x2.00" 4.00 by 2.00 inches
4.00x2.50" 4.00 by 2.50 inches
4.00x3.00" 4.00 by 3.00 inches
4.00x4.00" 4.00 by 4.00 inches
4.00x5.00" 4.00 by 5.00 inches
✓ 4.00x6.00" 4.00 by 6.00 inches
4.00x6.50" 4.00 by 6.50 inches
4.00x13.00" 4.00 by 13.00 inches
100mmx100mm 3.93 by 3.93 inches
100mmx120mm 3.93 by 4.72 inches
100mmx150mm 3.93 by 5.90 inches
100mmx170mm 3.93 by 6.68 inches
100mmx180mm 3.93 by 7.08 inches
100mmx200mm 3.93 by 7.86 inches
100mmx250mm 3.93 by 9.83 inches
SAMPLE LABEL
6 LB PRIORITY MAIL
ZONE 4 NO SURCHA
Printer
Presets
Copies
Pages
Paper Size
Orientation
☑ Auto Rotat
○ Scale:
● Scale to Fi
Copies per pa
Manage Custom Sizes...
PDF
Cancel
Print

② Create a new label size, rename, input width and height and check Non -Printable Area, then click "OK".


Paper Size
3
100*150mm
2
4*6
4 in
6
Height
Non-Printable Area
4
0 in
Top
0 in
Left
0 in
Right
0 in
Bottom
1
+
−
?
Cancel
OK
5

③ Choose the created size from "Paper Size".


Tools
Window
els-Sample.pdf
SAMPLE LABEL
6 LB PRIORITY MAIL
ZONE 4 NO SURCHA
Printer
Presets
Copies
Pages
Paper Size
Orientation
☑ Auto Rotat
○ Scale:
● Scale to Fi
Copies per pa
3.00x3.00" 3.00 by 3.00 inches
3.00x5.00" 3.00 by 5.00 inches
3.25x2.00" 3.25 by 2.00 inches
3.25x5.00" 3.25 by 5.00 inches
3.25x5.50" 3.25 by 5.50 inches
3.25x5.83" 3.25 by 5.82 inches
3.25x7.83" 3.25 by 7.82 inches
3.50x1.00" 3.50 by 1.00 inches
4.00x1.00" 4.00 by 1.00 inches
4.00x2.00" 4.00 by 2.00 inches
4.00x2.50" 4.00 by 2.50 inches
4.00x3.00" 4.00 by 3.00 inches
4.00x4.00" 4.00 by 4.00 inches
4.00x5.00" 4.00 by 5.00 inches
✓ 4.00x6.00" 4.00 by 6.00 inches
4.00x6.50" 4.00 by 6.50 inches
4.00x13.00" 4.00 by 13.00 inches
100mmx100mm 3.93 by 3.93 inches
100mmx120mm 3.93 by 4.72 inches
100mmx150mm 3.93 by 5.90 inches
100mmx170mm 3.93 by 6.68 inches
100mmx180mm 3.93 by 7.08 inches
100mmx200mm 3.93 by 7.86 inches
100mmx250mm 3.93 by 9.83 inches
4*6 4.00 by 6.00 inches

(5) Select "Printer Features" in "Preview", you can set up the printer properties here, such as "Media Tracking", "Darkness" and "Print speed".



Printer: PM-241-BT
Presets: Last Used Settings
Copies: 1
Pages: ● All ○ From: 1 to: 1
Paper Size: 4*6 4.00 by 6.00 inches
Orientation: ● Portrait ○ Landscape
☑ Auto Rotate
○ Scale:
● Scale to Fit:
Copies per page: 1



Printer: PM-241-BT
Presets: Last Used Settings
Copies: 1
Pages: ● All ○ From: 1 to: 1
Paper Size: 4*6 4.00 by 6.00 inches
Orientation: ● Portrait ○ Landscape
Printer Features
Feature Sets: Printer Settings
Media Tracking: Gap
Gap or Mark Height: 3mm
Gap or Mark Offset: 0mm
Darkness: Printer Default
Print Speed: Printer Default
ColorOption: None

① Select paper type in "Media Tracking". Choose among "Continuous", "Gap" or "Black Line".



Orientation: ● Portrait ○ Landscape
Printer Features
Media Tracking ✓ Gap
Gap or Mark Offset: 0mm
Darkness: Printer Default
Print Speed: Printer Default
ColorOption: None

② You can change the Printing Speed and the Darkness of your printing (Larger number means higher Darkness).



Printer: PM-241-BT
Presets: Last Used Settings
Copies: 1
Pages: ● All
○ From: 1 to: 1
Paper Size: 4*6 4.00 by 6.00 inches
Orientation: ● Portrait ○ Landscape
Printer Features
Feature Sets: Printer Settings
Media Tracking
Gap or Mark Height
Gap or Mark Offset
Darkness
Print Speed
ColorOption



Printer: PM-241-BT
Presets: Last Used Settings
Copies: 1
Pages: ● All
○ From: 1 to: 1
Paper Size: 4*6 4.00 by 6.00 inches
Orientation: ● Portrait ○ Landscape
Printer Features
Feature Sets: Printer Settings
Media Tracking: Gap
Gap or Mark Height: 3mm
Gap or Mark Offset: 0mm
Darkness: 8
Print Speed
ColorOption

(6) After setup, click "Print".



Printer: PM-241-BT
Presets: Last Used Settings
Copies: 1
Pages: ● All
○ From: 1 to: 1
Paper Size: 4*6 4.00 by 6.00 inches
Orientation: ● Portrait ○ Landscape
Printer Features
Feature Sets: Printer Settings
Media Tracking: Gap
Gap or Mark Height: 3mm
Gap or Mark Offset: 0mm
Darkness: 8
Print Speed: 5
ColorOption: None

Windows
STEP 1. Driver Installation

(1) **Double click on the installer to begin. Follow the installation steps until finish.**



Setup - Label Printer Driver Setup_Release_v1.2.7

Completing the Label Printer Driver Setup_Release_v1.2.7 Setup Wizard

Setup has finished installing Label Printer Driver Setup_Release_v1.2.7 on your computer. The application may be launched by selecting the installed shortcuts.

Click Finish to exit Setup.

(2) **To check if the printer is connected successfully:**

① Right click on "This PC", choose "Properties", then click on "Control panel" -> "Devices and Printers".


Open
Pin to Quick access
Manage
Pin to Start
Map network drive...
Disconnect network drive...
Create shortcut
Delete
Rename
Properties
1


System
Control Panel
...d Security > System
2
Control P...
View basic information about your computer
Device Manager
Remote settings
System protection
Advanced system settings
Windows edition
Windows 10 Pro
© 2018 Microsoft Corporation. All rights reserved.


Hardware and Sound
View devices and printers
3
Add a device
Adjust commonly used mobility settings

② Right click on "PM-241-BT" -> "Printer Properties"-> Click on "Print Test Page".


PM-24
See what's printing
Set as default printer
Printing preferences
Printer properties
Create shortcut
Remove device
Troubleshoot
Properties


PM-241-BT Properties

PM-241-BT

Location:

Comment:

Model: PM-241-BT

Features

Color: No

Double-sided: No

Staple: No

Speed: Unknown

Maximum resolution: 203 dpi

Paper available: 100mm x 150mm

Security
Device Settings
About
General
Sharing
Ports
Advanced
Color Management
Preferences...
Print Test Page
OK
Cancel
Apply

Windows
STEP 2. Printer Setup

C

(1) Set as default printer

Right click on "PM-241-BT" -> "Set as default printer".


PM-241-
See what's printing
Set as default printer
Printing preferences
Printer properties
Create shortcut
Remove device
Troubleshoot
Properties

(2) Select a paper type

① Right click on "PM-241-BT" -> choose "Printer Preferences".


PM-241-BT
See what's printing
✓ Set as default printer
Printing preferences
Printer properties
Create shortcut
Remove device
Troubleshoot
Properties

② Go to the "Page Setup".
You can choose the size you need in "Paper Name".


Page Setup
hics
Option
Settings
Rotate
Media Settings
Type
Gap
Gap
100mm x 150mm
100mm x 200mm
100mm x 210mm
101*74
105mm x 145mm
105mm x 150mm
105mm x 190mm
105mm x 200mm
105mm x 210mm
2.00" x 2.00" (50.8 x 50.8mm)
2.25" x 2.00" (57.1 x 50.8mm)
2.25" x 3.00" (57.1 x 76.2mm)
2.25" x 4.00" (57.1 x 101.6mm)
3.00" x 2.00" (76.2 x 50.8mm)
3.00" x 2.25" (76.2 x 57.1mm)
3.00" x 3.70" (76.2 x 94.0mm)
4.00" x 2.00" (101.6 x 50.8mm)
4.00" x 2.50" (101.6 x 63.4mm)
4.00" x 3.00" (101.6 x 76.2mm)
4.00" x 4.00" (101.6 x 101.6mm)
4.00" x 5.00" (101.6 x 127.0mm)
4.00" x 6.00" (101.6 x 152.4mm)
4.00" x 6.75" (101.6 x 171.4mm)

Paper Name: 100mm x 150mm

③ If there is no suitable label size for you, please click on "New" to create the needed size.


Layout
Page Setup
Graphics
Option
Settings
New
Edit
Delete
Rotate
ABCD
1234567
Media Settings
OK
Cancel
Apply

Paper Name: 4.00" x 6.00" (101.6 x 152.4mm)

● Portrait
○ Landscape
○ Portrait 180
○ Landscape 180

Type: Label With Gaps

Gap or Mark Height: 0.12 in

Gap or Mark Offset: 0.00 in

④ Change Paper name and input the width and the height, click "OK".


Paper config
OK
Cancel

Name: New

Type: Label

Width: 4.00 in

Height: 6.00 in

Left: 0.00 in

Right: 0.00 in

(3) Set up Print speed, Darkness and Size units

Go to "Option". You can change the printing speed, the Darkness and the size units of your printer (Larger number means higher Darkness) and click "Apply -> OK".


Layout
Page Setup
Graphics
Option
Command
Study gap label
Adjust the sensor
Settings
Adjustment
Media Handling
Size units
OK
Cancel
Apply

Print Speed: 5

Print Density: 8

Horizontal: 0.00 in

Vertical: 0.00 in

Post-Print: None

Occurrence: After Every Page

After-print: 0.00 in

● inch ○ mm

(4) Adjust the sensor and Study gap label.

Click "Adjust the sensor" to adjust printer sensor, then click "Study gap label" to let the printer learn the gap label.


Layout
Page Setup
Graphics
Option
Study gap label
Adjust the sensor
OK
Cancel
Apply

Print Speed: 5
Print Density: 8
Adjustment
Horizontal: 0.00 in
Vertical: 0.00 in
Media Handling
Post-Print: None
Occurrence: After Every Page
After-print: 0.00 in
Size units
● inch ○ mm

If printer flashes the blue light, it means that the learning has failed, then you need to repeat the above 2 button clicks again.

(5) Print a sample label: Open a desired file (e.g. a PDF).

① Click on "🖶"


Labels-Sample.pdf - Adobe Acrobat Pro DC
File Edit View Window Help
Home
Tools
Labels-Sample.pdf ×
1 / 1

② Select the printer "PM-241-BT".



Printer: PM-241-BT
Copies: 1
Pages to Print
● All
○ Current page

③ Preview and check the print size, then click "Print".


Scale: 100%
4 x 6 Inches
P
PRIORITY MAIL 2-DAY™
John Smith
1234 BARNES RD
CARSON NV 90000
99
SHIP TO:
DO NOT SHIP
11 CAMPBELL AVE
CAMPBELL CA 95009
USPS TRACKING #
8888888888888888888888888
DO NOT SHIP
<
>
Page 1 of 1
Print
Cancel

1. Adobe Use Tips

D

Adobe supports printing labels in both ways: Take Snapshot and Crop Pages (paid)
Position of function of Take Snapshot

(1) "View" -> "Show/Hide" ->"Toolbar Items" ->"show Edit Tools" -> "Take Snapshot"


View
Window
Help
Rotate View
Page Navigation
Page Display
Zoom
Tools
Show/Hide
❶
Display Theme
Read Mode Ctrl+H
Full Screen Mode Ctrl+L
Tracker...
Read Out Loud
Compare Files


Navigation Panes
Tools Pane Shift+F4
Toolbar Items
❷
Page Controls
✓ Menu Bar F9
Button Labels
Rulers & Grids
Cursor Coordinates


Show File Tools
Show Edit Tools
③
Show Page Navigation Tools
Show Page Display Tools
Show Select & Zoom Tools
Customize Quick Tools...
Hide Quick Tools
Show Recently Used Tools
Show Properties Bar Ctrl+E
Hide Toolbars F8
Reset Toolbars Alt+F8


Check Spelling
Undo
Redo
Cut
Copy
Paste
✓ Take Snapshot
④
✓ Find
Advanced Search
Show All Edit Tools
Reset Edit Tools

(2) "Edit" -> "Take a Snapshot" ->Drag the box over your label


ZHUHAISHI
ZHUHAISHI 519000
7725 8532 5882
INTL ECONOMY
FedEx
(TW)

If you want to know more about detailed tutorial, you can get it in the following ways:
Method 1: Complimentary USB driver (USB driver -> Support & How-Tos & Platform Setup -> 4.How-Tos & Platform Setup)
Method 2: Search for brand names on YouTube

2. Labelife Use Tips

D

Labelife is a free and customizable label software. You can use "Labelife" software to customize and print barcode labels on your desktop.

Labelife PC can be used by connecting the computer with power cord and USB cable. Labelife APP can be used by turning on the phone's Bluetooth to attach the printer

If you want to know more about detailed tutorial, you can get it in the following ways:
Labelife PC:Open Labelife PC —> Help —>Tutorial
Labelife App:Open Labelife App —>Setting—> Tutorial

3. Solution for Not Finding the Printer (Windows)

(1) Go to control panel -> Devices and Printers


Control Panel
Adjust your computer's settings
System and Security
Review your computer's status
Save backup copies of your files with File History
Backup and Restore (Windows 7)
Network and Internet
Hardware and Sound
View devices and printers
Add a device
Adjust commonly used mobility settings

(2) Click "Add a printer"


Control Panel
Add a device
Add a printer

(3) Click "The printer that I want isn’ t listed"


The printer that I want isn't listed

(4) Click "Add a local printer or network printer with manual setting" and click "next"


Add Printer
Browse...
Next
Cancel

Find a printer by other options

○ My printer is a little older. Help me find it.

○ Select a shared printer by name

Example: \\computername\printername or
http://computername/printers/printername/.printer

○ Add a printer using a TCP/IP address or hostname

○ Add a Bluetooth, wireless or network discoverable printer

● Add a local printer or network printer with manual settings

(5) To know which USB Port is connected, please right click on "This PC" and choose "Manage"->"Device Manager" -> "Universal Serial Bus controllers" ->Double click on "USB Printing Support"




Open
Pin to Quick access
Manage
Pin to Start
Map network drive...
Disconnect network drive...
Create shortcut
Delete
Rename
Properties


Computer Management
File Action View Help
Computer Management (Local
System Tools
Task Scheduler
Event Viewer
Shared Folders
Local Users and Groups
Performance
Device Manager
Storage
Disk Management
Services and Applications
SK-20200917UWGH
Audio inputs and outputs
Batteries
Bluetooth
Cameras
Computer
Disk drives
Display adapters
Firmware
Human Interface Devices
IDE ATA/ATAPI controllers
Intel(R) Dynamic Platform and Thermal Framework
Keyboards
Memory technology devices
Mice and other pointing devices
Monitors
Network adapters
Print queues
Printers
Processors
Software components
Software devices
Sound, video and game controllers
Storage controllers
System devices
Universal Serial Bus controllers
Generic USB Hub
Intel(R) USB 3.0 eXtensible Host Controller - 1.0 (Microsoft)
Standard Enhanced PCI to USB Host Controller
USB Composite Device
USB Printing Support
USB Root Hub
USB Root Hub (USB 3.0)
Actions
Device Manager
More Actions
1
2
3

① ->Go to "detail", choose "Bus relations" to check which USB port is connected


USB Printing Support Properties
General
Driver
Details
Events
❶
USB Printing Support


USB Printing Support Properties
General
Driver
Details
Events
USB Printing Support
Property
Device description
Device description
Device instance path
Hardware Ids
Compatible Ids
Capabilities
Status
Problem code
Config flags
Class
Class Guid
Inf name
Driver date
Driver version
Provider
Inf section
Matching device Id
Rank of driver
Service
Address
BIOS device name
Base container Id
Bus number
Bus relations
❷
Bus type Guid
Children
Configuration Id
Container Id
Device stack
Display name
Driver description


USB Printing Support Properties
General
Driver
Details
Events
USB Printing Support
❸

Property: Bus relations

Value: USBPRINT\4BARCODE4B-2064A\6&14d839c3&3USB001

② Select "USB001(Virtual printer port for USB)"and click "Next"


Add Printer
LPT1: (Printer Port)
LPT2: (Printer Port)
LPT3: (Printer Port)
COM1: (Serial Port)
COM2: (Serial Port)
COM3: (Serial Port)
COM4: (Serial Port)
COM5: (Serial Port)
COM6: (Serial Port)
FILE: (Print to File)
192.168.43.210 (Standard TCP/IP Port)
Desktop*.pdf (Adobe PDF)
Documents*.pdf (Adobe PDF)
Microsoft.Office.OneNote_16001.13801.20534.0_x64__8wekyb3d8bbwe
PORTPROMPT: (Local Port)
USB PORT: (Printer Port)
USB001 (Virtual printer port for USB)
USB002 (Virtual printer port for USB)

Choose a printer port

A printer port is a type of connection that allows your computer to exchange information with a printer.

● Use an existing port: USB PORT: (Printer Port)

○ Create a new port:

Type of port:

(6) Go back to the installation, click "Have Disk..."and click "Browse...". Select the file "QY.inf"in the installation path, then click "Open". (Default installation path: C:\Program Files\Label Printer\Label Printer\Driver)


Windows Update
Have Disk...
Next
Cancel


Locate File

Look in: Driver

Name	Date modified	Type
amd64	7/29/2021 8:03 PM	File fc
i386	7/29/2021 8:03 PM	File fc
ia64	7/29/2021 8:03 PM	File fc
QY.inf	6/23/2021 2:12 PM	Setup

File name: QY.inf

Files of type: Setup Information (*.inf)

Quick access
Desktop
Libraries
This PC
Network
Open
Cancel


Install From Disk

Insert the manufacturer's installation disk, and then make sure that the correct drive is selected below.

Copy manufacturer's files from:

OK
Cancel
Browse...

(7) Click "OK"and "Next".


Install From Disk

Insert the manufacturer's installation disk, and then make sure that the correct drive is selected below.

Copy manufacturer's files from: C:\Program Files\Label Printer\Label Printer\Driver

OK
Cancel
Browse...


Add Printer

Install the printer driver

Choose your printer from the list. Click Windows Update to see more models.

To install the driver from an installation CD, click Have Disk.

Printers
- PM-241
- PM-241-BT
- PM-246S
- PM-246S-BT

This driver has an Authenticode(tm) signature.

Tell me why driver signing is important

Windows Update
Have Disk...
Next
Cancel

(8) Click"Print a test page"and "Close", then click "Finish".


Add Printer

You've successfully added Phomemo PM-246S

☑ Set as the default printer

To check if your printer is working properly, or to see troubleshooting information for the printer, print a test page.

Print a test page
Finish
Cancel


PM-241-BT

A test page has been sent to your printer

This test page briefly demonstrates the printer's ability to print graphics and text, and it provides technical information about the printer. Use the printer troubleshooter if the test page does not print correctly.

Get help with printing